

QUICK INSTALLATION GUIDE OF NJ-81A33

Single Extension Slide, 200 pound (90 kgs) loading

READ THE QUICK INSTALLATION GUIDE FIRST BEFORE INSTALLATION

A. Columbus 1U server retail packaging includes – one pair of slides (NJ13002), 2 front bracket (W-239-B-1), 2 rear bracket (W-231-B-1), screw kit (S-060), 4 adjusting plates and installation instruction.


Screw kit (S-060) includes a. M5* 8,H 2.5 x 10 pcs b. M5*15, H 2.5 x 2 pcs c. M4*6, H 2.5 x 16 pcs d. M4*4, H2 x 10 pcs (black) e. #8-32*5, H2 x10 pcs f. Washer 4.2 * 11 * 0.8 x 10 pcs g. Nut M4 * 0.7 x 8 pcs

Technical Specifications for serve slides

1 NJ81A33 can work with chassis width from 424mm to 428mm, depending on the mounting (front of rail or behind rail) refer to Step4.

Step **7** > Install cabinet member to cabinet

Move the trigger to remove the inner (smallest) member from the outer (the biggest) member as shown on fig 1(Figure 1)





Step \mathbf{Z} > Mount inner member to the chassis

307.0 310.0

12.7

Mount inner member to the chassis as shown on fig 3 with at least 2 screws (M4) on each side. (Figure 2)






Step 4 > Attach brackets to the racks

J Mounting behind the rail as shown on fig4. For Chassis width less than 428mm, you may use optional rack mount brackess per EIA 310.

Step **5** > Insert the chassis into outer member

As shown on fig **5**. This instruction is for reference only. It may vary due to different applications.

J





(Figure 4)

