» Features

» Drawing

» Specification Table » Installation Instructions

### **Features**

Mounting | Side mount.

Side clearance | 7.5 mm Maximum chassis width can be 438 mm with bracket mounting behind the rail. Height | 39.3 mm


Loading | 75 pound (35 kgs) class for 1000 cycles. Size | 20" to 30" at 2" increment.

Feature | extremely thin profile to fit 438 mm wide chasis. SB tool-less along with lock open design and key holes for shoulder rivet.

Finish | RoHS compliant zinc plating.

Option | CMA.

#### **■** Profile



**■** Profile

(2=1)

#### **■** Surface Treatment


■ Clear Zinc ■ Black Zinc ■ Black E. Coating ■ White E Coating ■ Galvanized Steel Stainless Steel

#### Packaging

#### ■ Retail

\*Box QTY might vary with different length, the info provided here is based on 18" (450 mm)

### **Drawing**



**Specification Table** 

SIZE		А	В	С	D	Е	F	EXT
20"	(500mm)	508.0			276.3	92.1		532.7
22"	(550mm)	558.0	166.4	17.8	317.2		55.0	583.2
24"	(600mm)	609.6	166.4	17.8	368.4	92.1		634.3
26"	(650mm)	660.4	166.4	17.8	368.4	92.1	55.0	685.1
28"	(700mm)	711.0	166.4	17.8	460.5	92.1		735.9
30"	(750mm)	762 <u>.</u> 0	166.4	17.8	460.5	92.1	55.0	786.7

**Installation Instructions** 


## QUICK INSTALLATION GUIDE OF NJ-21G58

Samurai Tool-Less Server Slides, 75 pound (35 kgs) loading




# 4 STEPS TO THE SUCCESSFUL INSTALLATION!

- A. Please go through this guide thoroughly before installation. Please note that the 100 lb - grade SB Tool-less is designed and built for 1U and 2U chassis. Not recommended for 3U or above applications.
- B. The SB bracket is for EIA rail with 5/8" potch and square hole, and can only be mounted behind the rail. You will need to purchase transfer bracket in order to mount SB bracket on the rail with round holes. The standard retail packaging shall include one piece of left hand. one piece of right hand 4 pieces of H-370 screws for ear plate fastening and 2 pieces of H-207 screws for chassis fastening.




hole on bracket. SB Tool-less bracket is built for EIA bracket with square holes at 5/8" pitch. It doesn't work with 1/2" pitch.

# Step **1** > Remove the chassis (inner) member



## Step 2 > Mount the chassis (inner) member to the chassis


You may opt for M4 or M5 pan head screw. The screw head of either M4 or M5 can not exceed 2.0 mm. Alternatively, you may mount the slide member to the chassis through standoffs. Likewise, the head of stand-off can not exceed 2.0 mm. Each side of chassis is highly suggested to use 3 of screws or standoffs for slide attachment.



## Step 3 > Attach the cabinet (outer) member to the rail


Insert the stag into the upper and lower square holes on EIA rail from the back of rail. Push the safety lock forward to secure the bracket. It is important to





# Step 4 > Mount the chassis into the cabinet

Insert the chassis (inner) member into the cabinet member as shown on the drawing. It is important to check if the ball retainer is in fully open position before install the chassis. It might cause catastrophic damage to the chassis if ball retainer is not in fully open position while mounting the chassis. While you are pushing chassis back to the cabinet, you need to release the



Taiwan (R.O.C.)

www.repongroup.com

**T** + 886 - 3 - 3642777(Rep.) **F** + 886 - 3 - 3762777



