


NJ-28009

Pocket Door Slides
25 pound class (11 kgs)

Product Photo



Features



Mounting | Slide is mounted to the cabinet side panel.

Slide Clearance | Minimum 1/16" (1.5 mm) between door and cabinet.


Loading | 25 pound (11 kgs) class.

Size | 12"(300 mm) through 26"(650 mm) at 2"(50 mm) increment.

Feature | Designed to use wooden follower strip. Anti-sagging support rollers. Door hold-out feature, maximum door height is recommended to 48". Wooden follower strip and half overlay hinge is recommended.

Option | Guide roller and screw package.

Profile



Surface Treatment


- Clear Zinc
- Black Zinc
- Black E. Coating
- White E Coating
- Stainless Steel
- Galvanized Steel

Packaging


- Distribution / 12 pairs per box

*Box QTY might vary with different length, the info provided here is based on 18" (450 mm)

Drawing



Profile



Specification Table

SIZE	SL	TL	A	B	C	D	E
12" (300mm)	302.05	214.2		77.6	156.5	200.5	
14" (350mm)	352.85	265.0	103.4	128.4	207.3	251.3	
16" (400mm)	403.65	315.8	103.4	179.2	258.1	302.1	
18" (450mm)	454.45	366.6	103.4	230.0	308.9	352.9	
20" (500mm)	505.25	417.4	103.4	280.8	359.7	403.7	
22" (550mm)	556.05	468.2	103.4	331.6	410.5	454.5	
24" (600mm)	606.85	519.0	103.4	382.4	461.3	505.3	
26" (650mm)	657.65	569.8	103.4	433.2	512.1	556.1	160.0

Installation Instructions

QUICK INSTALLATION GUIDE OF NJ-28009


Pocket Door Slide, 25 pound (11 kgs) loading

READ THE INSTRUCTION THOROUGHLY BEFORE INSTALLATION

- A. Make sure all components are included in the package.
- 1 Right Hand and 1 Left Hand Pocket Door Slides
 - 18 5/8" Pan Head wood screws
 - 4 5/8" Flat Head wood screws
 - 4 4 M4 x 6 machine screws
 - 2 Guide Rollers
 - 2 23 mm wood screws
 - 2 Hinges (Bought Separately)

Attach wooden follower strip onto slides by pan head screws 5/8"


A. Cut wooden strip to the DIM. L (cabinet inner height-156 mm) x W (69 mm) x T (17 mm)



Step 1 > Mount the hinge plate onto slide by flat head screw M4 x 6 mm

Step 2 > Place slides as Figure A, then mount the lower side slide down to the cabinet bottom

DIM A1: Door thickness + 3 mm. Install pan head screws through horizontal slot holes for adjustment first, then screw the round hole for for fixing A.




Step 3 > Bore the hinge cup holes as shown on Figure B.

DIM B1: 39-40 mm is recommended.
DIM B2: 7-8 mm is recommended.
DIM B3: (Upper slide center to lower slide center distance) - 46 mm.

Step 4 > Mount the hinge cup onto the door by flat head 5/8" screws. See B.

Step 5 > Install the guide rollers on the top and bottom of cabinet as figure C.

DIM. C1: Door thickness + 9.5 mm (roller dia. / 2) + 9.8 mm slide thickness + 3 mm (movement clearance).
DIM. C2: Door thickness + 9.5 mm (roller dia. / 2)



Step 6 > Attach the door onto cabinet by hinges. (Bought Separately)

Tips on door gap adjustments. For upper and lower gaps, please adjust mounting plate vertical position.

Tips on door gap adjustments.

1. For upper and lower gaps, please adjust mounting plate vertically.
2. For door left or right door side gaps, please adjust C3.
3. Adjust C4 screw for door closure adjustment.

* The above DIM. might vary due to different manufacture and hinge types.

